

Cleaning's new



By: **ProClean**

Ready-to-use, food-safe glass and surface cleaner.

**ProClean Image** is your key to cleaner surfaces. In addition to **highly-active cleaning agents**, ProClean Image contains a **high-tech Anti-Soil and Anti-Fogging agent**, which leaves a protective, invisible film on the surface, reducing soil adhesion. Using ProClean Image will actually **reduce your cleaning frequency!**




Use **ProClean Image** to remove smudges, smears and other soils on:

- Glass
- Chrome
- Mirrors
- LCD Surfaces
- Other glossy surfaces



Available in 6x750ml, 4 x 5L or 15L



1) Proclean Image applied to 1 tile, not the other.



2) 1g of soil on each tile.



3) Tile placed vertically for 15 seconds.



4) Rinsed with distilled water